

## User Guide(LSLE1013F)

### **1.Reset:**

Press the red button for long time,green light will flash 12 times.All the previous data(reginstered fingerprints) are cancelled after long beep.

### **2.Register Fingerprints:**

Press the red buttun,when the reader show red light ,put your finger on the reader, beep sound'di,di',then beep again for long time.Registering is succeed after green light on.(If red light and green light flash at the same time,and beep 'di,di,di',registration fails).The memory of fingerpring registration is 32pcs.

### **3.Encode Password:**

Press '1' key,green light on,then press '#' + previous password + Start Button.When green light on,enter new password + Start Button;enter new password + Start Button again.When green light on,password encoding is succeed after beep for long time.

### **3.Door Access By Fingerprint:**

Press Start Buttun,when the fingerprint-reader show red light,put any registered fingerprint on the reader,beep sounds for long time.The lock will be released after green light showed on the reader.

**Notice:**If beep 'di,di,di',red light and green light flash at the same time,door release fails)

### **4.Door Access By Password:**

Enter the password + Start Button,green light on,the locker will be open after long-time beep.

### **5.Low Battery Indicator:**

If batter in low-power level,red light on.